



## AT A GLANCE



Aerosol, CFC & propellant free



Dry fragrance technology - no liquids, spills or sticky residues





Batteries last 2-3 months depending on quality and amount of light in the room



Made from fully recyclable EVA



Discreet - looks like a smoke detector



Coverage up to 25m squared



Versatile - position on a wall or ceiling at any height

It's time to ditch the aerosols and go greener. The discreet Easy Fresh fan air freshening system can be placed on a wall or ceiling without any spills thanks to it's dry fragrance technology, and the unique design ensures that fragrance from the recyclable cover is propelled around the room for the full 30 days. Light activated to conserve battery power, the Easy Fresh fan unit is designed to work harder as the cover nears the end of its life, to ensure an even fragrance delivery. Features low battery and cover change warning light on day 30 and an audible bleep on day 33, just in case you forget to change the cover.

FRAGRANCE	PRODUCT CODE	COLOUR
HONEYSUCKLE	WZEF72HS	0
SPICED APPLE	WZEF72SA	
OCEAN MIST	WZEF72OM	
COTTON BLOSSOM	WZEF72CB	
MANGO	WZEF72MG	
EASY FRESH FAN UNIT X 12	WZEFFAN12	

NOTE: As the fragrance in the cover is so powerful on install, the fan spins for only 10 seconds every 10 minutes during week one. This gradually increases as the month progresses, to run continuously during week four.

ACTIVE AIR FRESHENER RANGE





P-WAVE®

The highly fragranced, recyclable solution to air freshening



EASY FRESH FAN & COVER



## **HOW TO USE**



Remove fan from box and insert battery



Remove fragranced cover from bag



Fix fan unit to wall using either sticky pads or screw kit provided




Place fragranced cover on fan unit ensuring it is hooked over the plastic tabs top and bottom



Press button on the bottom of the fan unit to start the program for a month



Replace cover and recycle the old one after 30 days





ACTIVE AIR FRESHENER RANGE

P-WAVE®