

Lift Wax-Free Furniture Polish

Ideal for use on a wide variety of surfaces.

Easily removes a variety of soils, such as grease and finger marks.

Wax-free formulation to prevent build-up of waxes on surfaces.

A unique wax-free formulation, that offers superior cleaning whilst leaving a durable, high-gloss finish. Ideal for use on a wide variety of surfaces such as paintwork, enamel, laminates and sealed wooden surfaces. Designed to effectively remove a wide variety of soils such as dust and finger-marks leaving only a deep, long-lasting shine.

Also, available as a 5L refill pack for greater economy.

Not suitable for use in food preparation areas.

Directions for use

For professional use only.

Do not use on waxed or lacquered furniture.

1. Open the nozzle on the spray head.
2. Spray the product sparingly onto a soft, clean, dry cloth.
3. Allow to dry for a few seconds, then apply to the surface and polish to a shine.

For 5L refill packs:

Dispense into a heavy duty refill flask using a 5L tap dispenser.



2 x 5L | 052392X5



6 x 750ml | 057827



6 x 750ml HDR | 056553/6

Product Info

Colour: **White**

Fragrance: **Aromatic**

pH: **5.5 – 6.5**

Shelf Life: **24 Months**

CLEENOL

Tel: +44(0) 1295 251 721

Email: sales@cleenol.co.uk

Neville House, Beaumont Road, Banbury, Oxon. OX16 1RB.

Cleenol Group Ltd is a limited company registered in England and Wales under CRN 00635803.